



Upínač Whistle Notch pro upínací stopky

Upínač Whistle Notch DIN 6359 pro upínací stopky DIN 1835-E



Název	Kužel	d	D	A		G 2,5 25.000 min ⁻¹
BT40.50.WN.06.ADB	BT40	6	25	50	AD/B	•
BT40.50.WN.08.ADB	BT40	8	28	50	AD/B	•
BT40.63.WN.10.ADB	BT40	10	35	63	AD/B	•
BT40.63.WN.12.ADB	BT40	12	42	63	AD/B	•
BT40.63.WN.14.ADB	BT40	14	44	63	AD/B	•
BT40.63.WN.16.ADB	BT40	16	48	63	AD/B	•
BT40.63.WN.18.ADB	BT40	18	50	63	AD/B	•
BT40.63.WN.20.ADB	BT40	20	52	63	AD/B	•
BT40.90.WN.25.ADB	BT40	25	65	90	AD/B	•
BT40.100.WN.32.ADB	BT40	32	72	100	AD/B	•
BT40.120.WN.40.ADB	BT40	40	80	120	AD/B	•
BT50.63.WN.06.ADB	BT50	6	25	63	AD/B	•
BT50.63.WN.08.ADB	BT50	8	28	63	AD/B	•
BT50.63.WN.10.ADB	BT50	10	35	63	AD/B	•
BT50.80.WN.12.ADB	BT50	12	42	80	AD/B	•
BT50.80.WN.14.ADB	BT50	14	44	80	AD/B	•
BT50.80.WN.16.ADB	BT50	16	48	80	AD/B	•
BT50.80.WN.18.ADB	BT50	18	50	80	AD/B	•
BT50.80.WN.20.ADB	BT50	20	52	80	AD/B	•
BT50.100.WN.25.ADB	BT50	25	65	100	AD/B	•
BT50.105.WN.32.ADB	BT50	32	72	105	AD/B	•
BT50.110.WN.40.ADB	BT50	40	80	110	AD/B	•

od průměr d = 25 se dvěma upínacími šrouby